

THE ENOMODULE SERIES HAS BEEN DEVELOPED AS A BUILT-IN MODULAR SYSTEM, EACH UNIT OF WHICH HOLDS 8 BOTTLES. THE SYSTEM IS IDEAL FOR PERSONALISING MEDIUM TO LARGE FREE AREAS OF WALL SPACE WHERE WINES ARE SERVED AT ROOM TEMPERATURE. THE MODULES CAN CONNECT TOGETHER IN A SEAMLESS CONTINUITY OF BOTTLES, TO CREATE A UNIQUE VISUAL IMPACT.

## **eno**module

- Model:
  - enomodule 8 RT (8 bottle built-in module)
- Wine temperature: Room Temperature.
- Use and system activation: dispensers can be used either behind the counter (without wine card) or self-service (with wine card).
- Gas supply: food grade nitrogen or argon (cylinder or generator not included).
- Servings: 1 or 3 configurable volumes with touch screen key display.
- Display: each position has an LCD graphic touch screen interactive display to monitor the dispenser's functions. A central LCD graphic screen supplies general information.
- Materials: stainless steel.
- Lighting: double LED. Light intensity changes according to different functions.
- Environment control: an onboard controller performs a check on all external environment conditions (temperature, pressure, humidity) in order to auto-adjust the dispenser's efficiency. This guarantees increased precision of pour volumes and better functionality of the refrigeration system.
- Nitrogen/Argon leak control: a built in pressure control system highlights any gas leak directly on the display.
- Bottles lifting system: electrical pistons that avoid using air or gas for bottle activation.
- Positioning and placement: each module has the option

- being installed either free standing, or fastened directly to vertical surface side by side.
- Accessories upon request: lower cover, stainless steel side panel kit (entire or shaped), polycarbonate front panel with key lock (for installations "not built-in" we suggest the use of polycarbonate front panel together with entire side panels).
- Wine card types: chip card (SMART card) and RFID MIFARE (shared-use MAD system compatible). Finger print, magnetic stripe or bar code customizable upon request.
- Modules interfacing: LAN network, TCP/IP protocol.

entire stainless steel side panel kit



shaped stainless steel side panel kit



model	L	Н	D	weight	electrical requirements
-------	---	---	---	--------	-------------------------

enomodule 8 RT 882 mm (34.75") 671 mm (26.44") 234 mm (9.22") 29 kg (64 lbs) 115 / 230 V - 40 W